



Order no.	Spare part
5205005	Nozzle set complete with each 1x nozzle DANCE, BUBBLE and SPLASH
2615510	Filter cartridge (2 pieces)
7288158	Filter bottom
7377028	Connecting adapter for pump
7426270	Hose connector for hose-Ø. 1/2", 3/4" und 1", clamp ring and gasket

Order no.	Spare part
7426280	Adapter with sealing ring
7426290	Ceramic bush with rubber support (2 pieces)
7426300	Connection part not compatible with type 3351 and 3451
7482120	Pump cover with clamp ring and sealing ring
7475560	Set gasket
7478058	Extension set Filterbody with cartridge
7621388	Impeller (50 Hz)